

Advanced Setup is used to enable certain specific features or to modify standard settings. The order of the table below corresponds to the sequence on the on board LCD display of the basic viewer.

With on board LCD display or with RC:

To start the advanced setup with, press SETUP and ENTER simultaneously until 'ADVANCED SETUP' appears on the screen. Make selection via ↑ ↓ buttons, then press ENTER to confirm. Numbers are introduced digit by digit.

If TAC5 SC + MODBUS regulation:

For each feature of the advanced setup, the registry number is shown in the table. For more details see "TAC5 + MODBUS Installation Manual".

| Function | Description | TAC5 SC | | TAC5 SC + MODBUS Register n° |
|--|---|---------|------------------------|------------------------------|
| | | Step | Text on screen | |
| <i>For all working modes (CA, LS, CPs, TQ)</i> | | | | |
| Password | If password access is enabled, enter here the access code to enter advanced setup configuration. | 1 / 2 | ENTRER ACCES CODE 0000 | 40547 |
| <i>If SAT MODBUS plugged or no SAT on Modbus connector plugged</i> | | | | |
| Modbus configuration | Enter MODBUS communication configuration mode ? | 3 | MODBUS CONFIG? Y | / |
| Modbus Configuration | If yes, enter Modbus address of TAC5 unit | 3.1 | ADRESS : 001 | 40543 |
| Modbus Configuration | Select Baudrate : 1200-4800-9600-19200 Bauds | 3.2 | BAUDRATE 9600 | / |
| Modbus Configuration | Select Parity: N (none) – E (even) – O (odd) | 3.3 | PARITY : N | / |
| <i>If SAT ETHERNET plugged</i> | | | | |
| Ethernet configuration | Ability to configure the Ethernet communication settings: | 3 | LAN CONFIG? N | / |
| Ethernet configuration | Enter Ethernet communication configuration mode ? Select DHCP if the IP address of the unit is assigned dynamically Select MANUAL to enter a static IP address. | 3.1 | IP CNFG? DHCP | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the static ip address. 1 st step of 4. Example: if IP address is 193.100.0.23, enter here at step 1:193 | 3.1.1 | Ip address? 1/4 000 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the static ip address. 2 nd step of 4. Example: if IP address is 193.100.0.23, enter here at step 2:100 | 3.1.2 | Ip address? 2/4 000 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the static ip address. 3 rd step of 4. Example: if IP address is 193.100.0.23, enter here at step 3:0 | 3.1.3 | Ip address? 3/4 000 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the static ip address. 4 th step of 4. Example: if IP address is 193.100.0.23, enter here at step 4:23 | 3.1.4 | Ip address? 4/4 000 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the netmask. 1 st step of 4 | 3.1.5 | netmask? 1/4 255 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the netmask. 2 nd step of 4 | 3.1.6 | netmask? 2/4 255 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the netmask. 3 rd step of 4 | 3.1.7 | netmask? 3/4 255 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the netmask. 4 th step of 4 | 3.1.8 | netmask? 4/4 255 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the gateway. 1 st step of 4 | 3.1.9 | gateway? 1/4 000 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the gateway. 2 nd step of 4 | 3.1.10 | gateway? 2/4 000 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the gateway. 3 rd step of 4 | 3.1.11 | gateway? 3/4 000 | / |
| Ethernet configuration | If IP CNFG= MANUAL, enter the gateway. 4 th step of 4 | 3.1.12 | gateway? 4/4 000 | / |
| In all cases | | | | |
| RC takes back control of setup (after Modbus) | If setup and control features were made via Modbus, Wi-Fi, KNX, Ethernet communication, possibility here to switch control to a RC. | 4 | CONTROL BY RC ? Y | 40200 |

| <i>If LS working mode</i> | | | | |
|---|--|---------|--------------------------------|-------|
| Stop fans for certain 0-10V signal voltage values | Stop fans if actual 0-10V signal value < Vlow? | 5 / 6 | STOP FAN IF V<Vlow? N | 40501 |
| Stop fans for certain 0-10V signal voltage values | Enter Vlow value to stop fans if actual 0-10V signal value < Vlow | 6.1 | Vlow : 00,0 V | 40502 |
| Stop fans for certain 0-10V signal voltage values | Stop fans if actual 0-10V signal value > Vsup? | 7 / 8 | V>Vhigh? N | 40503 |
| Stop fans for certain 0-10V signal voltage values | Enter Vsup value to stop fans if actual 0-10V signal value > Vsup | 8.1 | Vhigh : 10,0 V | 40504 |
| <i>If CPs working mode</i> | | | | |
| Change Algorithm reaction speed | Configuration of the reaction speed of the CPs algorithm. 10 is Default value and is the highest reaction speed. Each -1 step corresponds to a doubling of the reaction time (10 = T, 9 = 2xT, 8 = 4xT, ...). The default value is determined for most ducting application, only special applications (constant pressure in a room) require to change this parameter. | 9 | SPEED CPs? 10 | 40506 |
| Change Algorithm reaction logic | Configuration of CPs mode operating logic: <ul style="list-style-type: none"> • Negative logic: <ul style="list-style-type: none"> - airflow rate drops when signal on K2 > assignment value - airflow rate rises when signal on K2 < assignment value • Positive Logic :: <ul style="list-style-type: none"> - airflow rate rises when signal on K2 > assignment value - airflow rate drops when signal on K2 < assignment value | 10 | LOGIC? NEGATIVE | 40507 |
| <i>If CA or LS working mode</i> | | | | |
| Stop fans when pressure alarm | Possibility to stop the fans in case of pressure alarm (after cancelling the alarm, press RESET to restart the fans. | 11 / 12 | PRESSURE ALARM STOP FAN? N | 40500 |
| <i>For all working modes (CA, LS, CPs, TQ)</i> | | | | |
| Change Starting Torque | Possibility to modify the fan's starting torque (2% default). | 13 / 14 | START TORQUE? 02% | 40508 |
| Disable softstop function (via control device) | Disable the possibility to stop the fans using the RC (remote control) via K1/K2/K3 circuit TAC5 SC. This feature corresponds to disabling the softstop function: - If RC master: the OFF key is disabled. - If TAC5 SC master: - CA mode: if no entries connected to K1/K2/K3 then K1 airflow is activated. - TQ mode: if no entries connected to K1/K2/K3 then K1 percentage of maximum fan torque is activated. - LS or CPs Mode: if K1 entry not connected to +12V, then control will operate as if K1 was connected to +12V. To do this select N (O is default value) | 15 / 16 | FANS OFF Y | 40509 |
| Input IN2 (if no MK3 option) | If Mk3 option is installed, IN2 input is then dedicated to it. Otherwise, select the function for digital input IN2: FIRE ALARM PRESSURE ALARM | 17/18 | INPUT IN2 : FIRE ALARM | 40555 |
| Boost function | Configure F1/F2 airflow rate (or percentage of maximum fan torque if torque modulation instead of airflow) in case of activation of Boost feature? | 19 | BOOST CONFIG? N | / |
| Boost function | Enter fan 1 airflow rate (or percentage of maximum fan torque if torque modulation instead of airflow) in case of activation of Boost feature? | 19.1 | FAN 1? xxx m³h ⁽¹⁾ | 40548 |
| Boost function (if 2 fans) | Enter fan 2 airflow rate (or percentage of maximum fan torque if torque modulation instead of airflow) in case of activation of Boost feature? | 19.2 | FAN 2? xxx m³h ⁽¹⁾ | 40549 |
| Fire Alarm | Configure fire alarm operating mode? | 20 | FIRE AL CONFIG? N | / |
| Fire Alarm | Select how fire alarm is activated when IN2 contact is dedicated to fire alarm : entry IN2 is N.O or N.C (normally open or normally closed): NO : alarm is activated when in2 contact closed NC : alarm is activated when in2 contact is open | 20.1 | CONTACT IN2? N.O | 40510 |
| Fire Alarm | Enter fan 1 airflow rate (or percentage of maximum fan torque if torque modulation instead of airflow) when fire alarm is activated. | 20.2 | FAN 1? 0000 m³h ⁽¹⁾ | 40511 |
| Fire Alarm (if 2 fans) | Enter fan 2 airflow rate (or percentage of maximum fan torque if torque modulation instead of airflow) when fire | 20.3 | FAN 2? | 40512 |

| | | | | |
|----------------------|--|--------|--------------------------------------|-------|
| | alarm is activated. | | 0000 m ³ h ⁽¹⁾ | |
| Output relay on SAT3 | Select the function for output relay OR1 in SAT3: ALARM Pa MK3 (mixing cabinet option) CT IN (motorized damper at inlet option) FAN ON | 21 | OR1 : ALARMPa | 40556 |
| Output relay on SAT3 | Select the function for output relay OR2 in SAT3: FAN ON ALARM Pa MK3 (mixing cabinet option) CT IN (motorized damper at inlet) | 22 | OR2: FAN ON | 40557 |
| KWext | If KWext option present, it is possible to modify the PID parameters. CAUTION: these modifications can be fatal and should only be carried out by qualified personnel. | 23 | CONFIG PID KW? N | / |
| KWext | KWext: possibility to modify PID parameter (PB) | 23.1 | KWextPID PB=005 | 40528 |
| KWext | KWext: possibility to modify PID parameter (Tr) | 23.2 | KWextPID Ti=030 | 40529 |
| KWext | KWext: possibility to modify PID parameter (Td) | 23.3 | KWextPID Td=011 | 40526 |
| BA | If BA option installed: Possibility to change the reaction speed configuration of the post heating algorithm (3 way valve regulation). Default value is '5' for a middle speed reaction time. Each step of -1 corresponds to a doubling of the reaction time ('5'=T, '4'=2xT, '3'=4xT, '2'=8xT, ...). Each step of +1 corresponds to a halving of the reaction time ('5'=T, '6'=T/2, '7'=T/4, '8'=T/8, ...). We recommend changing this value only if you experience T° stability problems in your application. | 24 | NV/BA SPEED 05 | / |
| SAT BA | Possibility to modify the regulation parameters of the heat exchangers regulated by the SAT BA/KW (option) | 25 | SAT BA? NO | / |
| SAT BA | Select coil type(s) regulate by the SAT BA/KW: BA+, BA-, BA+/-, BA+/BA-, KW, BA-/KW | 25.1 | TYPE BA? KW/BA- | 40550 |
| SAT BA | If BA+ option installed and regulated by SAT BA/KW : Possibility to change the reaction speed configuration of the post heating algorithm (3 way valve regulation). Default value is '5' for a middle speed reaction time. Each step of -1 corresponds to a doubling of the reaction time ('5'=T, '4'=2xT, '3'=4xT, '2'=8xT, ...). Each step of +1 corresponds to a halving of the reaction time ('5'=T, '6'=T/2, '7'=T/4, '8'=T/8, ...). We recommend changing this value only if you experience T° stability problems in your application. | 25.1.1 | BA SPEED 05 | 40526 |
| SAT BA | If BA- option installed and regulated by SAT BA/KW : Possibility to change the reaction speed configuration of the post heating algorithm (3 way valve regulation). Default value is '5' for a middle speed reaction time. Each step of -1 corresponds to a doubling of the reaction time ('5'=T, '4'=2xT, '3'=4xT, '2'=8xT, ...). Each step of +1 corresponds to a halving of the reaction time ('5'=T, '6'=T/2, '7'=T/4, '8'=T/8, ...). We recommend changing this value only if you experience T° stability problems in your application. | 25.1.2 | BA- SPEED 05 | 40551 |
| Comfort | In the presence of post-heating or post-cooling coil(s), regulation of the comfort T ° on supply (T5) or ambient (T2). The temperature measured on the selected sensor is used to determine the deviation from the setpoint for regulating the heating or cooling power. | 26 | COMFORT ON T5 | 40570 |
| Comfort | If comfort on T2, configuration of the reaction speed of the postheating/cooling. 8 is default value and is the normal reaction speed. Each -1 step slows down and corresponds to a doubling of the reaction time (8 = T, 7 = 2xT, 6 = 4xT,....). Each +1 step speeds up and corresponds to a diving of the reaction time (8 = T, 9 = T/2, 10 = T/4). | 26.1 | COMF. SPEED?08 | 40571 |
| Comfort | If comfort on T2, lower limit of the temperature reached in supply flow (T5), active when post-cooling. Protection to prevent an excessively cold blowing. Range: 0 to 22°C | 26.2 | T5 MIN 15°C | 40572 |
| Comfort | If comfort on T2, upper limit of the temperature reached in supply flow (T5), active when post-heating. Protection to prevent excessively warm blowing. Range: 16 to 50°C | 26.3 | T5 MAX 28°C | 40573 |
| Post ventilation | Enable post-ventilation feature (allow fans to run during a certain amount of time after softstop is activated). Caution: if Post-heat KWext is installed, the post-ventilation feature is automatically enabled. It is then impossible to set it to 'NO'. | 27 | POST VENT? N | 40532 |
| Post ventilation | Enter post-ventilation time (in seconds) Caution: if post electrical heating KWext, time must be of at least 90 seconds. | 27.1 | TIME PV 0090 sec | 40533 |
| Operating time | Possibility to enable a fan operating time counter feature. The purpose is to report a maintenance alarm and/or to stop the fans after a certain time of operation. | 28 | FAN RUN TIME? N | 40534 |

| | | | | |
|----------------|--|--------|--------------------------|----------------|
| Operating time | Reset operating time counter to 0 | 28.1 | TIME RESET? N | 40252 |
| Operating time | Enable display of operating time | 28.2 | DISPLAY TIME? N | 40535 |
| Operating time | Enable maintenance alarm after a certain operating time? | 28.3 | SERVICE ALARM? N | 40536 |
| Operating time | Enter operating time limit (in hours) to generate a maintenance alarm. | 28.3.1 | TIME? 000000 h | 40537 40538 |
| Operating time | Enable 'fan stop' alarm after a certain operating time? | 28.4 | STOP FAN? N | 40539 |
| Operating time | Enter operating time limit (in hours) to generate a 'fan stop' alarm. The fans will be stopped after this limit is passed. | 28.4.1 | TIME? 000000 h | 40540 40541 |
| Alarm display | Possibility to display only the alarms on the graphic screen. If no alarm is activated then "Vent OK" is displayed. | 29 | DISPLAY ALARM ONLY? N | 40542 |
| Backward fan | Only with fan code corresponding to backward: select yes if pressure sensor at fan inlet for CA mode (kit CA). | 30 | BW WITH SENSOR? N | 40607 |
| Backward fan | Only with fan code corresponding to backward with kit CA: possibility to change the K-factor parameter of the fan. | 30.1 | K-FACTOR ?xxx | 40559 |
| Backward fan | Only with fan code corresponding to backward with kit CA: Select the maximum output voltage of the kit CA pressure sensor (5 or 10 V DC) | 30.2 | MAX VOLT ? 5V | 40568 |
| Backward fan | Only with fan code corresponding to backward with kit CA: change the maximum operating pressure of the kit CA pressure sensor (Pa) | 30.3 | MAX dPa Pa? xxxx | 40569 |
| Mode TQ | Select yes to work with torque modulation instead of airflow. This is automatically the case for backward fan without kit CA (then this menu is not displayed) | 31 | MODE TQ? N | 40608 |
| Access Code | Possibility to activate an access code to allow access to setup and advanced setup. | 32 | ACCESS CODE? N | 40546 |
| Access Code | Enter access code to setup and advanced setup (4 decimals). | 32.1 | CODE 0000 | 40547 |
| Full Reset | Possibility to operate a general factory reset. All factory settings are then regenerated. | 33 | FACTORY RESET? N | 40251 |
| | End of advanced setup | 34 | END SETUP | |

⁽¹⁾: in case of torque modulation instead of airflow, that is when "mode TQ" is selected in product setup or when the unit has backward fans without pressure sensor at inlet, the percentage of maximum fan torque will be entered in "%TQ" instead of the airflow in "m³/h".